

UPDU CLI Reference Manual

Riedo Networks Ltd
Switzerland

Revision: 2.10.2-8cb1e874

Date: August 31, 2023

Contents

1	UPDU CLI	4
1.1	Using the UPDU CLI	4
1.2	Command Line Editing and Command History	4
1.3	Contextual Help	4
1.4	Command Abbreviation	5
1.5	Comments	5
1.6	Output Filtering	5
1.7	Get Help	5
1.8	Logout	5
1.9	Reboot UPDU	5
1.10	Schedule reboot UPDU	6
1.11	Cancel a schedule reboot UPDU	6
1.12	Show CLI History	6
1.13	Clear CLI History	6
1.14	Clear Screen	6
1.15	Show Monitoring Conditions	6
1.16	Show Configuration	7
1.17	Show Network Interface Information	7
1.18	Show IP Information	7
1.19	Show Modbus/TCP Register Map	7
1.20	Show Reboot	7
1.21	Show Monitoring Rules	8
1.22	Show SNMP EngineID	8
1.23	Show Spanning Tree Protocol Status	8
1.24	Show SSH Server Host Key Fingerprint	8
1.25	Show System Time	8
1.26	Show Version	9
2	Logging	10
2.1	Show System Log	10
2.2	Clear System Log	10
2.3	Real-Time Log	10
3	Measurement Values	11
3.1	Show Instantaneous Power	11
3.2	Show Energy Counters	11
3.3	Show Sensor Measurements	11
4	UPDU Information	12
4.1	Show Wiring	12
4.2	Show Module Information	12
5	Residual Current Monitoring (RCM)	13
5.1	Show Residual Current	13
5.2	Show RCM Information	13
5.3	Show RCM Statistics	13
5.4	RCM Module Test	13
6	Power over Ethernet (PoE)	14
6.1	Show Power over Ethernet Information	14
7	Outlet Switching	15
7.1	Switch Outlet Off	15
7.2	Switch Outlet On	15
7.3	Power Cycle Outlet	15

8	Tracing	16
8.1	Enable Tracing	16
8.2	Disable tracing	16
9	Identify Object (UID)	17
10	Configuration Mode	18
10.1	Execute Normal Commands	18
10.2	Device Name Configuration	18
10.3	Hostname Configuration	19
10.4	Factory Reset	19
10.5	Save Configuration	19
10.6	Screen Blanker Configuration	19
10.7	RADIUS Configuration	20
10.8	LDAP Configuration	21
10.9	Authentication Method Order	24
10.10	Network Interface Configuration	24
10.11	General Network Configuration	27
10.12	Spanning Tree Protocol (STP) Configuration	28
10.13	Time Configuration	29
10.14	Simple Network Management Protocol (SNMP) Configuration	30
10.15	Webserver Configuration	33
10.16	Telnet Configuration	36
10.17	Users Configuration	36
10.18	SSH Configuration	38
10.19	Modbus/TCP Configuration	39
10.20	Logging	40
10.21	UPDU Object Configuration	40
10.22	SSL/TLS Certificates Configuration	44
11	Licenses	46
11.1	Activate Licenses	46
11.2	Show Licenses	46
12	UPDU Log Messages	47
12.1	Log Levels and Log Facilities	47
12.2	Monitoring Messages	47
12.3	Audit Messages	48

1 UPDU CLI

The UPDU CLI gives access to all parts of the UPDU. It can be accessed through the AUX3 port or through SSH and Telnet.

1.1 Using the UPDU CLI

The UPDU CLI is structured into two modes:

- User mode: allowing to get system information, work with measurement data, toggle outlets etc.
- Configuration mode: allowing mode to change UPDU settings.

When in user mode, the prompt is composed of the hostname and ">":

```
updu-100499>
```

In the configuration mode, the prompt changes:

```
updu-100499(config)#
```

Unless documented otherwise, commands entered in the configuration mode are effective immediately but are not persisted until the "write" command is invoked.

1.2 Command Line Editing and Command History

The command line can be edited using the Left and Right keys, using Backspace, Delete, End and Home.

A history of already entered commands is kept. It can be accessed using the Up and Down keys.

Furthermore, the following key combinations are available:

- CTRL-a: moves the cursor the start of the line
- CTRL-b: moves the cursor left one character
- CTRL-c: clears the current line and refreshes the prompt
- CTRL-d: deletes the character under the cursor; if pressed on an empty line, exits the current mode or the CLI session when already in the main commands
- CTRL-e: moves the cursor to the end of the line
- CTRL-f: moves the cursor right one character
- CTRL-k: deletes from the cursor to the end of the line
- CTRL-l: refreshes the current line
- ALT-b: moves the cursor backward one word
- ALT-f: moves the cursor forward one word
- ALT-Backspace: deletes the word left of the cursor

1.3 Contextual Help

Entering a question mark (?) at the prompt gives information about the currently entered command or shows a list of all available commands matching an partially entered command.

1.4 Command Abbreviation

The UPDU CLI allows commands to be abbreviated to the number of letters that make them unique. For example, it is sufficient to enter `sh conf` for `show config`.

Some commands are explicitly exempted from command abbreviation.

Note that depending on the commands that will be added in future versions of the UPDU firmware, it is possible that the minimal number of letters for a specific command may change.

1.5 Comments

Text after an exclamation mark (!) or a hash (#) character is ignored by the CLI. This allows to have comments in configurations.

1.6 Output Filtering

Some commands, mainly the `show` commands, allow their output to be filtered to display only selected parts of the output. Example:

```
updu-100499> show power | include module
Module1          0.0      231.0      0      0
```

The following output filters are supported:

- `begin PATTERN` : Filter anything until a line containing `PATTERN` appears.
- `include PATTERN` : Print all lines containing `PATTERN`.
- `exclude PATTERN` : Filter all lines containing `PATTERN`.
- `section PATTERN` : Show the first matching section. A section is a sequence of lines where the first one starts with the string `PATTERN` and all subsequent lines are further indented than the first line.

The case is ignored for the pattern matching.

1.7 Get Help

Enter `help` for an online help.

1.8 Logout

The `logout` command terminates the current CLI session:

```
updu-100499> logout
Bye...
```

1.9 Reboot UPDU

The `reboot` command reboots the UPDU:

```
updu-100499> reboot
Rebooting...
```

By default, only the Interface and Controller Module (ICM) is rebooted, the individual metering modules and the Ethernet switch on ETH1/ETH2 continues running.

To also reboot these peripherals, use these commands:

- Reboot the ICM and the metering modules:

```
updu-100499> reboot modules
Rebooting...
```

- Reboot the ICM and the Ethernet switch:

```
updu-100499> reboot switch
Rebooting...
```

- Reboot the ICM, the metering modules and the Ethernet switch:

```
updu-100499> reboot all
Rebooting...
```

1.10 Schedule reboot UPDU

A reboot can be scheduled with `reboot in <minutes>`.

1.11 Cancel a schedule reboot UPDU

Cancel a scheduled reboot (`reboot in X` command) with `reboot cancel`.

1.12 Show CLI History

The `show history` command shows the CLI commands in the history. The Up and Down keys can be used to navigate through the commands.

```
updu-100499> show history
1. show power
2. show energy
3. show history
```

1.13 Clear CLI History

The command history can be cleared using the `clear history` command.

1.14 Clear Screen

The `clear screen` command clears the screen and puts the cursor at the top left position.

1.15 Show Monitoring Conditions

To see active conditions, use the `show conditions` command:

```
updu-100499> show conditions
Start      Object      Metric      Status
2023-03-17 14:33:23 PDU          Voltage     WARNING (>235.0V)
```

Likewise, past conditions can be seen with the `show conditions history` command:

```
updu-100499> show conditions history
Start      End          Object      Metric      Status
2023-03-17 14:33:23 2023-03-17 14:40:10 PDU          Voltage     WARNING (>235.0V)
```

1.16 Show Configuration

The `show config` command shows the currently active UPDU configuration.

Certificate and private key data is hidden by default. In order to show the entire configuration, use the `show config all` command.

1.17 Show Network Interface Information

The `show interface` command shows the status of the UPDU's network interfaces:

```
updu-100499> show interface
ETH1
  link up
  mac-address d4:66:a8:10:09:1e
ETH2
  link down
  mac-address d4:66:a8:10:09:1e
ETH3
  link down
  mac-address d4:66:a8:10:09:1d
```

1.18 Show IP Information

The `show ip` command shows the current TCP/IP setup:

```
updu-100499> show ip
ETH1/2
  ipv4 address 192.168.111.28/24
  ipv4 gateway 192.168.111.1
  ipv4 dns-server 192.168.111.1
  ipv6 link-local fe80::d666:a8ff:fe10:1123
  ipv6 global fc00:0:0:1::3000
  ipv6 prefix fc00:0:0:1::/64
  ipv6 gateway fe80::250:b6ff:fe14:2de7
  ipv6 dns-server fc00:0:0:3::
ETH3
  ipv4 address n/a
  ipv6 link-local n/a
  ipv6 global n/a
  ipv6 prefix n/a
  ipv6 gateway n/a
```

1.19 Show Modbus/TCP Register Map

The `show modbus/tcp` command shows which Modbus/TCP register ranges correspond to which object. To get the detailed list of registers, use `show modbus/tcp detail`.

1.20 Show Reboot

The 'show reboot' command shows information whether a reboot is scheduled or not. If a reboot is scheduled, the remaining time until reboot is shown.

```
updu-100499> show reboot
No reboot scheduled
updu-100499> reboot in 15
Scheduled reboot in 15 minutes
updu-100499> show reboot
Device will reboot in 14:57
```

1.21 Show Monitoring Rules

The configured monitoring rules and their state can be displayed with the `show rules` command:

```
updu-100499> show rules
Object      Metric      State
PDU         Voltage     CRITICAL HIGH (>242.0V)
WireL1      Current     OK (<12.0A)
WireL2      Current     WARNING HIGH (>12.0A)
WireL3      Current     OK (<12.0A)
```

1.22 Show SNMP EngineID

The `show snmp engineid` command shows the UPDU's unique EngineID:

```
updu-100499> show snmp engineid
8000d74403d466a810091d
```

1.23 Show Spanning Tree Protocol Status

The `show spanning-tree` command shows the current STP status:

```
updu-100499> show spanning-tree
Version: RSTP

Bridge ID: 32768-d4:66:a8:10:09:1e
Bridge hello time: 2
Bridge max age: 20
Bridge forward delay: 15

Topology changes count: 0
Root bridge ID: 32768-d4:66:a8:10:09:1e

Interface  Role      Status
ETH1       designated forwarding
ETH2       disabled  broken
```

1.24 Show SSH Server Host Key Fingerprint

The `show ssh-hostkey` shows the fingerprint of the SSH host key in OpenSSH format.

```
updu-100499> show ssh-hostkey
Fingerprint: SHA256:WG3ha0d4z/myt1IqNfCb5pGBYB/MTioYHvFU+W4mLVg
```

1.25 Show System Time

To see the date, time, uptime and the time of the last SNTP update, use the `show time` command:


```
updu-100499> show time
Date: 2021-10-18
Time: 11:11:30 UTC
Local Date/Time: 2021-10-18 13:11:30 timezone CEST
Last SNTP update: 0h48:00 ago
Uptime: 0h48:06
```

1.26 Show Version

The `show version` information shows information about the PDU and about the currently running firmware, about the backup firmware and about the firmware for the PIM/POM modules which is embedded in the currently running firmware image:

```
updu-100499> show version
PDU model: RN3005
PDU serial-number: 100499
PDU part-number: 100-0603-1
PDU lot-number: 2137CA
Running UPDU firmware: 2.3.0-DEV-dd4920fe
Backup UPDU firmware: 2.3.0-DEV-55f5449a
Embedded PIM/POM firmware: 3.3.1-d17622cb
RTOS: 2.6.0
Network stack: TCP 2.1.2/SSL 2.1.2/Crypto 2.1.2/SSH 2.1.2/STP 2.1.2
Toolchain: GCC 10.3.0
```

2 Logging

2.1 Show System Log

The `show log` command shows content of the system log buffer. Messages logged by the system are written into that buffer. If the buffer is full, old messages are rotated out of the buffer.

Log messages are formatted as follows:

```
[timestamp] level facility: message
```

By default, the timestamp is the uptime of the device when the message was logged.

- Using the `show log utc` command, the timestamp is converted to UTC.
- Using the `show log localtime` command, the timestamp is converted to the configured local time

(requires the clock to be synchronized, otherwise the system assumes the device has booted at 1/1/1970).

The other components are:

- `level` : One of `err` (error), `wrn` (warning), `inf` (information) or `dbg` (debugging).
- `facility` : Tells which part of the system logged the message.

2.2 Clear System Log

The log is cleared using the `clear log` command.

2.3 Real-Time Log

To activate a real-time log of the syslog messages into the current CLI session, use the `monitor log` command:

```
updu-100499> monitor log
Real-time log monitoring enabled
...
```

All logged messages are now printed in the current CLI session in real-time. To disable the real-time log, use `monitor log off` :

```
updu-100499> monitor log
Real-time log monitoring disabled
...
```

3 Measurement Values

3.1 Show Instantaneous Power

The `show power` command shows the latest current, voltage and power measurements available:

```
updu-100499> show power
Object      Name                I [A rms]  U [V rms]  P [W]  Q [var]
PDU         cabinet3-4          0.0        0.0        0       0
WireL1      0.0                0.0        0       0
WireL2      0.0                0.0        0       0
WireL3      0.0                0.0        0       0
WireN       0.0                n/a        n/a      n/a
...
```

Legend: I: Current, U: Voltage, P: Active power, Q: Reactive power

With `show power description`, the object descriptions are added to the output.

3.2 Show Energy Counters

The `show energy` shows the energy counters:

```
updu-100499> show energy
Object      Name                A+ [kWh]  R1 [kvarh]  R4 [kvarh]
PDU         cabinet3-4          4.039     0.000       2.019
WireL1      4.038              0.000       2.019
WireL2      0.000              0.000       0.000
WireL3      0.000              0.000       0.000
Branch1     0.109              0.025       0.001
Branch2     0.109              0.026       0.000
Branch3     0.109              0.025       0.000
...
```

Legend:

A+: Positive active energy

R1: Positive reactive energy (quadrant 1)

R4: Negative reactive energy (quadrant 4)

With `show energy description`, the object descriptions are added to the output.

3.3 Show Sensor Measurements

The `show sensor` command shows the measurements of the sensors plugged into the AUX ports:

```
updu-100499> show sensor
Object      Name                Port      T [C]  RH [RH%]
Sensor1     SensorBottom       AUX1      n/a     n/a
Sensor2     SensorBottom       AUX2      23.2   34.4
Sensor3     SensorBottom       AUX3      n/a     n/a
```

Legend: T: Temperature, RH: Relative Humidity

With `show sensor description`, the object descriptions are added to the output.

4 UPDU Information

4.1 Show Wiring

The `show wiring` shows the electrical structure of the UPDU along with the installed options, such as `RCM`, `Relay` and `OVP` :

```
PDU [RCM,OVP]
├ WireL1
│   └ Branch1
│       └ Module1
│           ├── Outlet1.1 [Relay]
│           ├── Outlet1.2 [Relay]
│           ├── Outlet1.3 [Relay]
│           ├── Outlet1.4 [Relay]
│           ├── Outlet1.5 [Relay]
│           ├── Outlet1.6 [Relay]
│           ├── Outlet1.7 [Relay]
│           └ Outlet1.8 [Relay]
...
└ WireN
```

4.2 Show Module Information

The `show module info` command shows information about all available modules.

```
updu-100499> show module info
module slot 0: Module1
  label 1
  part-number 100-0290-3
  serial-number 1006954
  lot-number "2132DA"
  image-1
    status RUNNING
    version 3.3.1-d17622cb
  image-2
    status BACKUP
    version 3.3.0-d9ded1fe
  nominal 16 A 230 V
  outlets
    0: C13 Outlet, 10 A
    1: C13 Outlet, 10 A
    2: C13 Outlet, 10 A
    3: C13 Outlet, 10 A
    4: C13 Outlet, 10 A
    5: C13 Outlet, 10 A
    6: C19 Outlet, 16 A
    7: C19 Outlet, 16 A
  ...
```

5 Residual Current Monitoring (RCM)

5.1 Show Residual Current

On UPDUs equipped with an RCM module, the residual current can be shown using the `show rcm` command:

```
updu-100499> show rcm
Object      Name                RMS [mA rms]    DC [mA]
RCM                               0.7            0.3
```

Legend: RMS: RMS residual current, DC: DC residual current

With `show rcm description`, the object descriptions are added to the output.

5.2 Show RCM Information

The `show rcm info` command gives more information about the RCM modules:

```
updu-100499> show rcm info
Object      Info
RCM         S/N: 2002514564, APP: 107, API: 256, SW: 604
```

5.3 Show RCM Statistics

The `show rcm stats` command shows statistics related to the communication with the RCM module:

```
updu-100499> show rcm stats
Object      tx  timeouts  unexp  crc  excep
RCM         2426      0        0     0     0
```

Data fields:

- `tx` : Number of commands sent to the RCM module
- `timeouts` : Number of commands timed out
- `unexp` : Number of unexpected responses
- `crc` : Number of CRC errors
- `excep` : Number of reported exceptions

5.4 RCM Module Test

RCM modules have a built-in selftest function. The test takes about 2 seconds, during which the RCM values are not updated.

```
updu-100499> test rcm
PDU          Test OK
```

6 Power over Ethernet (PoE)

6.1 Show Power over Ethernet Information

The `show poe` command is used to show information on Power over Ethernet. The following states exist:

- `PoE powered` : The UPDU is currently powered by PoE.
- `AC powered, supplying PoE power` : The UPDU is mains powered and is providing power to another device by PoE.
- `AC powered, not supplying PoE power` : The UPDU is mains powered and is not providing power to another device by PoE.

Example:

```
updu-100499> show poe
PoE powered
```

7 Outlet Switching

Outlets equipped with relays can be switched on and off individually. Outlets are identified using the module label and the outlet number printed on the PDU.

7.1 Switch Outlet Off

Outlets can be switched off using the `outlet off` command:

```
updu-100499> outlet off Outlet1.3
```

7.2 Switch Outlet On

Outlets can be switched on using the `outlet on` command:

```
updu-100499> outlet on Outlet1.1
```

7.3 Power Cycle Outlet

To power cycle an outlet, use the `outlet cycle` command. The outlet in question is switched off and on again after five seconds:

```
updu-100499> outlet cycle Outlet1.7
```

8 Tracing

Some aspects of the UPDU can be traced for debugging purposes. When tracing is enabled, additional debugging log messages are logged. By default, tracing is switched off for all modules.

8.1 Enable Tracing

To enable tracing a functionality, use the `trace enable` command.

Example: Enable tracing RADIUS authentication:

```
updu-100499> trace enable radius
```

8.2 Disable tracing

To disable tracing a functionality, use the `trace disable` command. To disable all tracing, use `trace disable all`.

Example: Disable tracing RADIUS authentication:

```
updu-100499> trace disable radius
```


9 Identify Object (UID)

The UID function (short for unit identification) is useful to help an on-site engineer to find a PDU, a module or an outlet by blinking the outlet LEDs of the selected object. It is activated with the `identify` CLI command.

By default, the UID function is active for 5 minutes.

Examples:

- Identify a module:

```
updu-100499> identify Module2
updu-100499>
```

- Identify Outlet2.3 during 60 seconds:

```
updu-100499> identify Outlet2.3 60
updu-100499>
```

- Stop a running UID function:

```
updu-100499> identify stop
updu-100499>
```

10 Configuration Mode

When the `configure` command is entered, the configuration mode is activated. The configuration mode provides a number of sub-modes which allow configuring a specific part of the system.

Sub-modes can be left using the `exit` command. `exit` in the main configuration mode leaves the configuration mode and returns into the normal mode.

The prompt reflects the currently active mode.

Example configuration session modifying the hostname:

- Enter the configuration mode:

```
updu-100499> configure
updu-100499(config)#
```

- Enter the `system` configuration sub-mode:

```
updu-100499(config)# system
updu-100499(config-system)#
```

- Change the hostname to `my-pdu` :

```
updu-100499(config-system)# hostname my-pdu
my-pdu(config-system)#
```

- Return to the main configuration mode:

```
my-pdu(config-system)# exit
my-pdu(config)#
```

- Return to the normal mode:

```
my-pdu(config)# exit
my-pdu>
```

Unless documented otherwise, commands entered in the configuration mode are effective immediately but are not persisted until the “write” command is invoked.

10.1 Execute Normal Commands

Some non-configuration commands can be executed while being in the configuration mode. Simply prepend the desired command with `do`.

Example:

```
updu-100499(config)# do show power
Name                I [A rms]  U [V rms]  P [W]  Q [var]
PDU                  0.0        233.3    0       0
Module 1             0.0        233.3    0       0
...
```

10.2 Device Name Configuration

The device name is configured in the `system` configuration sub-mode. It is shown in the web interface and used as `sysName` in the SNMP MIB-II System Group.

Example:

```
updu-100499> configure
updu-100499(config)# system
updu-100499(config-system)# device-name servers-pdu
updu-100499(config-system)# system
```

10.3 Hostname Configuration

The hostname can be configured in the `system` configuration sub-mode. It is used in DHCP requests.

Example:

```
updu-100499> configure
updu-100499(config)# system
updu-100499(config-system)# hostname mypdu
mypdu(config-system)#
```

10.4 Factory Reset

The `factory-reset` command resets settings to their factory defaults and reboots the UPDU. If requested, network settings (interface configuration and spanning-tree protocol settings) can be preserved in order not to lose connectivity when the factory reset is initiated remotely.

Examples:

- Do a factory reset:

```
updu-100499> factory-reset full
Enter "YES" if you really want to reset all settings to their
factory defaults and reboot the UPDU:
```

- Do a factory reset but preserve the current network settings:

```
updu-100499> factory-reset preserve-network
Enter "YES" if you really want to reset all settings (except network
settings) to their factory defaults and reboot the UPDU:
```

By specifying the `force` parameter, the interactive confirmation can be skipped (e.g. for scripting).

The `factory-reset` command cannot be abbreviated.

10.5 Save Configuration

The `write` command saves the current configuration to flash.

10.6 Screen Blanker Configuration

By default, the UPDU display is switched off after 10 minutes of inactivity. This behaviour can be changed in the `display` configuration sub-mode.

- Disable the screen blanker:

```
updu-100499> configure
updu-100499(config)# display
updu-100499(config-display)# blank-time off
updu-100499(config-display)#
```

- Blank the display after 5 minutes:

```
updu-100499> configure
updu-100499(config)# display
updu-100499(config-display)# blank-time 5:00
updu-100499(config-display)#
```

10.7 RADIUS Configuration

RADIUS (short for Remote Authentication Dial In User Service) allows a UPDU to authenticate users on a RADIUS server without having to create them locally on the UPDU. When RADIUS is enabled and configured, the username and password of users trying to log in is sent to the RADIUS server which verifies if the user has access and which then responds with the roles of that user.

10.7.1 RADIUS Server Setup

In order to transmit user roles to the UPDU, a vendor specific attribute called "RNX-UPDU-Roles" consisting of a string with a comma-separated list of roles must be configured for each user.

For FreeRADIUS, this can be achieved with this setting in the `dictionary` configuration file:

```
VENDOR RNX 55108
ATTRIBUTE RNX-UPDU-Roles 1 string RNX
```

Users can now be configured as follows:

```
bob      Cleartext-Password := "bobspassword"
        RNX-UPDU-Roles = "admin"
```

10.7.2 Enable or disable RADIUS

- Disable RADIUS:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# radius disabled
updu-100499(config-auth)#
```

- Enable RADIUS:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# radius enabled
updu-100499(config-auth)#
```

10.7.3 RADIUS Server Address

The hostname or IP address of the RADIUS server is configured using the `radius server` command.

Examples:

- Set the RADIUS server to `authserver.local` :

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# radius server authserver.local
updu-100499(config-auth)#
```

The `radius server` command also allows to configure the port to which RADIUS requests are sent. If not specified, port 1812 is used.

Examples:

- Use port 21812 for RADIUS authentication requests:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# radius server authserver.local auth-port 21812
updu-100499(config-auth)#
```

10.7.4 RADIUS Shared Secret

The RADIUS shared secret is configured using the `radius shared-secret` command.

Examples:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# radius shared-secret "I am secret!"
updu-100499(config-auth)#
```

Notes:

- The RADIUS shared secret is stored in clear text and is shown with the `show config` command.

10.7.5 Various RADIUS Options

The RADIUS timeout option controls how long the UPDU waits for a response from the RADIUS server until it considers retransmitting it. The timeout is given in milliseconds and defaults to 2000 ms:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# radius timeout 2000
updu-100499(config-auth)#
```

The RADIUS retries option defines how many times a timed out request is retransmitted until it is declared failed. By default it does 3 retries:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# radius retries 3
updu-100499(config-auth)#
```

10.8 LDAP Configuration

LDAP (short for Lightweight Directory Access Protocol) allows a UPDU to authenticate users on a authentication server providing LDAP interface without having to create them locally on the UPDU. When LDAP is enabled and configured, the username and password of users trying to log in is sent to the LDAP authentication server which verifies if the user has access and which then responds with the groups the user is member of.

Supported authentication server is Microsoft Active Directory.

10.8.1 Configuration of a Microsoft Active Directory User

In order to authenticate a user with certain UPDU roles, it is necessary for the user to be member of at least one group with the name RNX-UPDU-[role].

Example : User bob is member of groups RNX-UPDU-admin and RNX-UPDU-snmp-read.

10.8.2 Enable or Disable LDAP Authentication

- Disable LDAP:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# ldap disabled
updu-100499(config-auth)#
```

- Enable LDAP:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# ldap enabled
updu-100499(config-auth)#
```

10.8.3 LDAP Server Address

The hostname or IP address of the LDAP authentication server is configured using the `ldap server` command.

Examples:

- Set the LDAP server to `authserver.local` :

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# ldap server authserver.local
updu-100499(config-auth)#
```

10.8.4 LDAP Transport

The TCP transport mode is configured using the `ldap transport` command.

Examples:

- Set the LDAP transport to plain:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# ldap transport plain
updu-100499(config-auth)#
```

- Set the LDAP transport to tls:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# ldap transport tls
updu-100499(config-auth)#
```

The `ldap transport` command also allows to configure the port to which LDAP requests are sent. If not specified, port 389 for plain and port 636 for tls transport are used.

Examples:

- Use port 1636 for LDAP tls requests:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# ldap transport tls port 1636
updu-100499(config-auth)#
```

10.8.5 LDAP Bind Authentication

In order for the UPDU to request the LDAP authentication server, a user having read access is on the LDAP directory is required.

Examples:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# ldap bind-auth CN=admin,CN=Users,DC=authserver,DC=local "I am secret!"
updu-100499(config-auth)#
```

or with the Active Directory logon name:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# ldap bind-auth admin@authserver.local "I am secret!"
updu-100499(config-auth)#
```

Notes:

- The LDAP bind password is stored in clear text and is shown with the `show config` command.

10.8.6 LDAP Base Search DN

A base DN may be given point in the directory where to start the search for the user.

Examples:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# ldap base-dn CN=Users,DC=authserver,DC=local
updu-100499(config-auth)#
```

10.8.7 LDAP Login Name Attribute

The Login Name Attribute may be adapted according to your LDAP schema. By default it is set to `sAMAccountName`.

Examples:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# ldap login-name-attribute sAMAccountName
updu-100499(config-auth)#
```

In Active Directory this may be set to `userPrincipalName` for users to authenticate with their AD logon name.

Examples:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# ldap login-name-attribute userPrincipalName
updu-100499(config-auth)#
```

10.8.8 LDAP Request Timeout

The timeout in milliseconds may be configured for all LDAP requests.

Examples:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# ldap timeout 2000
updu-100499(config-auth)#
```

10.9 Authentication Method Order

The UPDU tries to authenticate users locally first. When a user exists locally, remote authentication methods are skipped.

When the authenticating user does not exist locally, the remote authentication methods RADIUS and LDAP are tried, depending on what is configured.

If both RADIUS and LDAP are configured, the order of the remote authentication methods can be changed with the `order` command. By default, RADIUS is tried before LDAP.

Example:

- Authenticate LDAP before RADIUS:

```
updu-100499> configure
updu-100499(config)# auth
updu-100499(config-auth)# order local ldap radius
updu-100499(config-auth)#
```

Note that the `order` command does not disable or enable authentication methods.

10.10 Network Interface Configuration

The `interface` configuration sub-mode can be used to modify interface settings.

10.10.1 Link Configuration

The following network interface link settings are available:

- `enabled` : The interface is active. This setting is available for ETH1 and ETH3.
- `disabled` : The interface is shut down.
- `bridged-to-eth1` : The interface is bridged to ETH1. This setting is only available for ETH2.

Examples:

- Disable an interface:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# link disabled
updu-100499(config-interface-ETH1)#
```

- Enable an interface:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# link enabled
updu-100499(config-interface-ETH1)#
```

- Bridge ETH2 to ETH1:

```
updu-100499> configure
updu-100499(config)# interface ETH2
updu-100499(config-interface-ETH2)# link bridged-to-eth1
updu-100499(config-interface-ETH2)#
```


10.10.2 IPv4 Configuration

Network interfaces can be configured to use a static IP address or to use DHCP to get a dynamic IP address.

Examples:

- Disable IPv4:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv4 disabled
updu-100499(config-interface-ETH1)#
```

- Static IP address, netmask and gateway:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv4 address 192.168.1.100/24 gateway 192.168.1.1
updu-100499(config-interface-ETH1)#
```

- Use DHCP, fall-back to AutoIP after 30 seconds (default setting):

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv4 dhcp autoip-fallback 30
updu-100499(config-interface-ETH1)#
```

- Use DHCP, disable AutoIP fall-back:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv4 dhcp autoip-fallback off
updu-100499(config-interface-ETH1)#
```

10.10.3 IPv4 DNS Configuration

For each network interface, up to two IPv4 DNS servers can be configured:

- No IPv4 DNS servers:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv4 dns-server none
updu-100499(config-interface-ETH1)#
```

- Automatically configure IPv4 DNS servers:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv4 dns-server auto
updu-100499(config-interface-ETH1)#
```

- Set two IPv4 DNS servers:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv4 dns-server 8.8.8.8 8.8.4.4
updu-100499(config-interface-ETH1)#
```

10.10.4 DNS Lookups

DNS Lookups are done using the DNS servers configured on the default outbound network interface (see Default Outbound Interface).

If the default outbound network interface has IPv6 active, the UPDU first does IPv6 lookups. If that lookup fails, it falls back to IPv4 lookups.

10.10.5 IPv6 Configuration

The following IPv6 configuration options are available:

- Disable IPv6:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv6 disabled
updu-100499(config-interface-ETH1)#
```

- Stateless address autoconfiguration (SLAAC):

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv6 slaac
updu-100499(config-interface-ETH1)#
```

- DHCPv6: Use stateful DHCPv6 to get an IPv6 address and discover the network prefix and default gateway automatically:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv6 dhcpv6
updu-100499(config-interface-ETH1)#
```

- Static IPv6 address and gateway:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv6 address fc00:0:0:1::1234/64 gateway fc00:0:0:1::
updu-100499(config-interface-ETH1)#
```

- Static IPv6 with automatic gateway discovery:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv6 address fc00:0:0:1::1234/64
updu-100499(config-interface-ETH1)#
```

If the prefix length is statically configured as `/0`, the prefix will also be discovered automatically.

10.10.6 IPv6 DNS Configuration

For each network interface, up to two IPv6 DNS servers can be configured:

- No IPv6 DNS servers:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv6 dns-server none
updu-100499(config-interface-ETH1)#
```

- Automatically configure IPv6 DNS servers:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv6 dns-server auto
updu-100499(config-interface-ETH1)#
```

- Set up to two IPv6 DNS servers:

```
updu-100499> configure
updu-100499(config)# interface ETH1
updu-100499(config-interface-ETH1)# ipv6 dns-server 2001:4860:4860::8888 2001:4860:4860::8844
updu-100499(config-interface-ETH1)#
```

See DNS Lookups for information on how DNS lookups are done.

10.11 General Network Configuration

The `network` configuration sub-mode can be used to modify general network settings.

10.11.1 Default Outbound Interface

The interface to be used for outbound traffic can be configured as follows:

- Use ETH1 and ETH2 (if ETH2 is bridged to ETH1):

```
updu-100499> configure
updu-100499(config)# network
updu-100499(config-network)# default-outbound ETH1/ETH2
updu-100499(config-network)#
```

- Use ETH3:

```
updu-100499> configure
updu-100499(config)# network
updu-100499(config-network)# default-outbound ETH3
updu-100499(config-network)#
```

10.11.2 Clear DNS Cache

The DNS cache of the default outbound interface can be cleared using the `clear dns-cache` CLI command.

10.11.3 Broadcast and Multicast Storm Protection

The storm protection feature limits the bandwidth of broadcast and multicast traffic on the switch which backs the ETH1 and ETH2 interfaces. When enabled, broadcast, and optionally, multicast traffic exceeding 2% of the available link bandwidth is dropped as it enters ETH1 and ETH2.

This feature helps to mitigate problems caused by switching loops, which use up CPU resources of UPDUs and can cause UDPUs to become unreachable.

Broadcast and multicast storm protection is enabled by default. It can be enabled or disabled in the `network` section of the configuration:

- Switch off storm protection:

```
updu-100499> configure
updu-100499(config)# network
updu-100499(config-network)# switch storm-protection disabled
updu-100499(config-network)#
```

- Enable storm protection for broadcast traffic only:

```
updu-100499> configure
updu-100499(config)# network
updu-100499(config-network)# switch storm-protection broadcast
updu-100499(config-network)#
```

- Enable storm protection for broadcast and multicast traffic:

```
updu-100499> configure
updu-100499(config)# network
updu-100499(config-network)# switch storm-protection broadcast multicast
updu-100499(config-network)#
```

10.12 Spanning Tree Protocol (STP) Configuration

The `spanning-tree` configuration sub-mode can be used to modify spanning tree protocol settings. The spanning tree protocol is used on ETH1 and ETH2.

10.12.1 Enable or Disable STP

- Enable STP:

```
updu-100499> configure
updu-100499(config)# spanning-tree
updu-100499(config-stp)# enabled
updu-100499(config-stp)#
```

- Disable STP:

```
updu-100499> configure
updu-100499(config)# spanning-tree
updu-100499(config-stp)# disabled
updu-100499(config-stp)#
```

10.12.2 Select STP Bridge Priority

The STP bridge priority can be configured using the `bridge-priority` command.

Examples:

- Set bridge priority to 0:

```
updu-100499> configure
updu-100499(config)# spanning-tree
updu-100499(config-stp)# bridge-priority 0
updu-100499(config-stp)#
```

- Set bridge priority to 32768 (default value):

```
updu-100499> configure
updu-100499(config)# spanning-tree
updu-100499(config-stp)# bridge-priority 32768
updu-100499(config-stp)#
```

10.12.3 Set STP Timers

The STP hello time, max-age and forward delay timers can be set using the `stp-timers` command:

Example:

- Set timers to the default values

```
updu-100499> configure
updu-100499(config)# spanning-tree
updu-100499(config-stp)# stp-timers hello-time 2 max-age 20 forward-delay 15
updu-100499(config-stp)#
```

10.12.4 Select STP Version

The UPDU supports both the traditional Spanning Tree Protocol (802.1d) well as the Rapid Spanning Tree Protocol (802.1w).

- Select the traditional Spanning Tree Protocol:

```
updu-100499> configure
updu-100499(config)# spanning-tree
updu-100499(config-stp)# version STP
updu-100499(config-stp)#
```

- Select the Rapid Spanning Tree Protocol:

```
updu-100499> configure
updu-100499(config)# spanning-tree
updu-100499(config-stp)# version RSTP
updu-100499(config-stp)#
```

Note that if you use the traditional Spanning Tree Protocol together with DHCP, the default `autoip-fallback` of 30 seconds may need to be increased. See IPv4 Configuration.

10.13 Time Configuration

The time settings consist of a Simple Network Time Protocol (SNTP) server address and a poll interval. The UPDU polls the specified server regularly and updates its time accordingly.

10.13.1 Set SNTP Poll Interval

Examples:

- Configure the factory-default 60 minutes:

```
updu-100499> configure
updu-100499(config)# time
updu-100499(config-time)# sntp poll-interval 60
updu-100499(config-time)#
```

10.13.2 Set SNTP Server Address and Port

Examples:

- Configure the factory-default SNTP server with the default port (123):

```
updu-100499> configure
updu-100499(config)# time
updu-100499(config-time)# sntp server pool.ntp.org
updu-100499(config-time)#
```

- Configure a local SNTP server with a non-standard port:

```
updu-100499> configure
updu-100499(config)# time
updu-100499(config-time)# sntp server timeserver.company.com port 1123
updu-100499(config-time)#
```

10.13.3 Set the local time

There are 2 different ways to configure the local time:

- By specifying a system known timezone. This method implies daylight saving time.
- By creating a custom local time with a fixed offset from UTC.

Examples:

- Configure a system timezone :

```
updu-100499> configure
updu-100499(config)# time
updu-100499(config-time)# local zone Europe/Berlin
updu-100499(config-time)#
```

- Configure a custom time offset from UTC:

```
updu-100499> configure
updu-100499(config)# time
updu-100499(config-time)# local offset -01:00 "myzone UTC-1"
updu-100499(config-time)#
```

- Use UTC:

```
updu-100499> configure
updu-100499(config)# time
updu-100499(config-time)# local UTC
updu-100499(config-time)#
```

10.14 Simple Network Management Protocol (SNMP) Configuration

The `snmp` configuration context is used to modify all SNMP related settings.

10.14.1 Enable or Disable SNMPv2

SNMP version 2 is enabled or disabled as follows:

- Enable SNMPv2:

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# snmpv2 enabled
updu-100499(config-snmp)#
```

- Disable SNMPv2:

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# snmpv2 disabled
updu-100499(config-snmp)#
```

10.14.2 Configure SNMPv2 Read Access

In order to enable SNMPv2 read access, a community string has to be configured. This is done as follows:

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# snmpv2 read enabled community very-secret-abc*123
updu-100499(config-snmp)#
```

SNMPv2 read access is disabled as follows:

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# snmpv2 read disabled
updu-100499(config-snmp)#
```

10.14.3 Configure SNMPv2 Write Access

In order to enable SNMPv2 write access, a community string has to be configured. This is done as follows:

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# snmpv2 write enabled community very-secret-abc*123
updu-100499(config-snmp)#
```

SNMPv2 write access is disabled as follows:

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# snmpv2 write disabled
updu-100499(config-snmp)#
```

10.14.4 SNMP Version 3

SNMP version 3 can be enabled or disabled as follows:

- Enable SNMPv3:

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# snmpv3 enabled
updu-100499(config-snmp)#
```

- Disable SNMPv3:

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# snmpv3 disabled
updu-100499(config-snmp)#
```

When SNMPv3 is enabled, all users which are enabled for SNMPv3 have access according to their user role.

10.14.5 Set SNMP SysContact

The MIB-II System Group contact is configured as follows:

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# syscontact system-admin@best-datacenter.domain
updu-100499(config-snmp)#
```

10.14.6 Set SNMP SysLocation

The MIB-II System Group location is configured as follows:

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# syslocation "Cabinet 1, Row 4, Floor 2"
updu-100499(config-snmp)#
```

10.14.7 Enable or Disable SNMP MIBs

It is possible to enable or disable MIBs with the `mib` command. The following MIBs are available:

- `updu-mib2` : The UPDU MIB2, defined in the file `RNX-UPDU-MIB2.mib` . This is the latest, recommended MIB and is enabled by default.
- `updu-mib1` : The UPDU MIB1, defined in the file `RNX-UPDU-MIB1.mib` . This MIB is obsolete and not recommended to use for new installations. It is enabled by default.
- `e3meter-mib` : A subset of the RNX E3METER IPS PDUs, making it possible to monitor the PDU with existing monitoring software. Described in `e3meter-ipm-stripped.mib` . This MIB is disabled by default.

Examples:

- Disable the `updu-mib1` :

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# mib updu-mib1 disabled
updu-100499(config-snmp)#
```

- Enable the `updu-mib1` :

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# mib updu-mib1 enabled
updu-100499(config-snmp)#
```

10.14.8 Configure SNMP Notifications

Notifications can be sent to up to three SNMP receivers using SNMP Trap or Inform messages. Notifications are sent for events from the monitoring system and for audit events. Thus, in order to receive SNMP notifications, refer to *UPDU Object Configuration* for details on how to configure monitoring settings.

Notes:

- Inform messages require the receiver to acknowledge reception. If not acknowledged within two seconds the UPDU tries to re-send the messages up to five times.
- In order for notifications to be sent, the `updu-mib2` MIB and the corresponding SNMP version needs to be enabled. For SNMPv3, the mentioned user must be configured.
- For SNMPv3 Traps, the UPDU's SNMP Engine ID has to be configured at the receiver.
- Only a single notification setting can be enabled per host address. This is because the host address is used as unique identifier for the notification. **An existing configuration for the same host address is replaced without confirmation.**

Examples:

- Send SNMPv2 Trap messages to 192.168.1.1 with community `alert` :


```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# notify-host 192.168.1.1 snmpv2-trap community alert
```

- Send authenticated and encrypted SNMPv3 Inform messages to `192.168.1.123` with the user `event`. Note that a system user has to be created in order to use the SNMPv3 authentication against a host.

```
updu-100499> configure
updu-100499(config)# users
updu-100499(config-users)# user event
Created new user event.
updu-100499(config-users-event)# snmpv3 enabled
updu-100499(config-users-event)# snmpv3 auth sha1 password yes-its-me
updu-100499(config-users-event)# snmpv3 privacy aes password very-secret
updu-100499(config-users-event)# exit
updu-100499(config-users)# exit
updu-100499(config)# snmp
updu-100499(config-snmp)# notify-host 192.168.1.123 snmpv3-inform user event
```

To delete a notification receiver, use the `delete` command:

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# delete notify-host 192.168.1.1
```

10.14.9 Enable or Disable SNMP Options

The following SNMP functions can be controlled using the `option` command in the SNMP configuration mode:

- `write-object-info`: When enabled, properly authenticated SNMP write requests (i.e. carrying the correct SNMPv2 write community or matching SNMPv3 username/authentication/privacy information) can be used to modify object name and description, which are exposed as `upduMeterCustomName` and `upduMeterDescription` in the RNX-UPDU MIB. This functionality is disabled by default. It is only shown in the `show config` output if enabled.

When disabled, SNMP write requests can only be used to switch outlets on and off.

Examples:

- Enable `write-object-info`:

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# option write-object-info enabled
updu-100499(config-snmp)#
```

- Disable `write-object-info`:

```
updu-100499> configure
updu-100499(config)# snmp
updu-100499(config-snmp)# option write-object-info disabled
updu-100499(config-snmp)#
```

10.15 Webserver Configuration

The `webserver` configuration sub-mode can be used to modify the built-in webserver settings.

10.15.1 Enable or Disable HTTP

Enable HTTP:

```
updu-100499> configure
updu-100499(config)# webserver
updu-100499(config-webserver)# http enabled
updu-100499(config-webserver)#
```

Disable HTTP:

```
updu-100499> configure
updu-100499(config)# webserver
updu-100499(config-webserver)# http disabled
updu-100499(config-webserver)#
```

10.15.2 Enable or Disable HTTPS

Enable HTTPS:

```
updu-100499> configure
updu-100499(config)# webserver
updu-100499(config-webserver)# https enabled
updu-100499(config-webserver)#
```

Disable HTTPS:

```
updu-100499> configure
updu-100499(config)# webserver
updu-100499(config-webserver)# https disabled
updu-100499(config-webserver)#
```

10.15.3 Webserver Redirection

The `redirect` configuration directive allows to configure the webserver to redirect requests as follows:

- `redirect http disabled` : No redirection of unencrypted requests (URLs starting with `http://`).
- `redirect https disabled` : No redirection of encrypted requests (URLs starting with `https://`).
- `redirect http https` : All unencrypted requests are redirected to an encrypted `https://` URL. No other unencrypted data is sent by the webserver. This is the factory default. If HTTPS is disabled, this setting has no effect.
- `redirect https updu.io` : All requests to an https URL containing an IP address are redirected to the corresponding URL under the `updu.io` domain name. This setting has no effect if a custom SSL/TLS certificate is active.

Examples:

- Disable all redirections:

```
updu-100499> configure
updu-100499(config)# webserver
updu-100499(config-webserver)# redirect http disabled
updu-100499(config-webserver)# redirect https disabled
```

- Redirect http to https and to the updu.io domain:

```
updu-100499> configure
updu-100499(config)# webserver
updu-100499(config-webserver)# redirect http https
updu-100499(config-webserver)# redirect https updu.io
```

This causes e.g. requests to `http://192.168.1.100` to be redirected to `https://192-168-1-100.updu.io`.

10.15.4 Enable or Disable HTTP Strict Transport Security (HSTS)

When HTTP Strict Transport Security is enabled, clients will no longer communicate with the UPDU over non-encrypted HTTP connections but directly use HTTPS.

HSTS is disabled by default. When enabled, HSTS is used with `max-age=31536000` (one year), subdomains are not included.

Enable HSTS:

```
updu-100499> configure
updu-100499(config)# webserver
updu-100499(config-webserver)# hsts enabled
updu-100499(config-webserver)#
```

Disable HSTS:

```
updu-100499> configure
updu-100499(config)# webserver
updu-100499(config-webserver)# hsts disabled
updu-100499(config-webserver)#
```

10.15.5 Select the SSL/TLS Certificate

By default, the webserver uses a built-in wildcard certificate for the `updu.io` domain. In addition to this static certificate, the webserver can be configured to use a custom certificate uploaded to the PDU (see *SSL/TLS Certificates Configuration*).

The certificate is selected using the `certificate` command in the webserver configuration sub-mode.

Examples:

- Use the built-in `*.updu.io` wildcard certificate:

```
updu-100499> configure
updu-100499(config)# webserver
updu-100499(config-webserver)# certificate built-in
```

- Use the certificate configured in certificate store 1:

```
updu-100499> configure
updu-100499(config)# webserver
updu-100499(config-webserver)# certificate store-1
```

- Use the certificate configured in certificate store 2:

```
updu-100499> configure
updu-100499(config)# webserver
updu-100499(config-webserver)# certificate store-2
```

If the chosen certificate is incomplete (i.e. the private key or the certificate is missing or invalid), the webserver will automatically fall-back to the built-in `updu.io` certificate. As soon as the chosen certificate is corrected, it is activated immediately.

10.16 Telnet Configuration

The `telnet` configuration sub-mode allows to control the telnet service.

- Enable telnet.

```
updu-100499> configure
updu-100499(config)# telnet
updu-100499(config-telnet)# enabled
updu-100499(config-telnet)#
```

- Disable telnet:

```
updu-100499> configure
updu-100499(config)# telnet
updu-100499(config-telnet)# disabled
updu-100499(config-telnet)#
```

By default, telnet is disabled.

10.16.1 Telnet Session Timeout

By default, telnet sessions are automatically terminated after 15 minutes of inactivity. This timeout can be changed as follows:

- Disable telnet session timeout:

```
updu-100499> configure
updu-100499(config)# telnet
updu-100499(config-telnet)# session-timeout off
updu-100499(config-telnet)#
```

- Terminate inactive telnet sessions after 1 hour:

```
updu-100499> configure
updu-100499(config)# telnet
updu-100499(config-telnet)# session-timeout 60
updu-100499(config-telnet)#
```

Changing the timeout doesn't apply to established sessions, only to new sessions.

10.17 Users Configuration

The `users` configuration sub-mode can be used to configure users.

10.17.1 Add or Modify a User

The `user` command in the users configuration sub-mode selects the user to modify. If the user doesn't exist yet, a new user without any roles and without a password is created.

When a user is selected, the prompt changes to include the username of the selected user. In this mode, the following commands can be used to modify the user:

- `password <PASSWORD>` : Set a new password, given in clear-text. The clear-text password is transformed using an irreversible function and the resulting hash is stored in the configuration.
- `password-hash <HASH>` : Set the user's password to the specified hash.
- `roles set <ROLE>...` : Set the desired roles of the user.
- `roles none` : Clear all roles.

- `ssh-key add <KEY-DATA>` : Adds the specified SSH public key to this user. Using SSH public keys, users can log in without providing a password. Up to 8 keys can be configured for each user.
- `ssh-key delete <ID>` : Deletes the user's SSH public key identified by `<ID>` .
- `ssh-key <ID> <KEY-DATA>` : Set a user's SSH public key, `<ID>` being the number of the key (between 1 and 8).

The following user roles are available:

- `guest` : Guest users are essentially read-only users without any administrative permissions.
- `admin` : Administrator users have full control over all aspects of a UPDU.
- `snmp-read` : SNMP read permission (for SNMPv3).
- `snmp-write` : SNMP write permission (for SNMPv3).

SSH public keys have to be in OpenSSH format (key format identifier followed by the key all on a single line). The following key types are supported: `ssh-ed25519` , `ecdsa-sha2-nistp256` , `ecdsa-sha2-nistp384` , `ecdsa-sha2-nistp521` and `ssh-rsa` . `ssh-rsa` keys have to be between 2048 and 4096 bits (note that the CLI currently does not verify the key length so it is possible to configure shorter keys but they will not work for authentication).

Examples:

- Select the `admin` user and set a new password:

```
updu-100499> configure
updu-100499(config)# users
updu-100499(config-users)# user admin
updu-100499(config-users-admin)# password VerySecurePassword
```

- Create a new guest user with password `visitor` :

```
updu-100499> configure
updu-100499(config)# users
updu-100499(config-users)# user guest
Created new user guest.
updu-100499(config-users-guest)# roles set guest
updu-100499(config-users-guest)# password visitor
```

- Allow the `admin` user to log in using a SSH public key:

```
updu-100499> configure
updu-100499(config)# users
updu-100499(config-users)# user admin
updu-100499(config-users-admin)# ssh-key add "ssh-rsa ..."
```

User passwords are stored as PBKDF2-SHA256 hashes. The `show config` command shows the hash.

10.17.2 Delete a User

To delete a user, use the `delete` command:

```
updu-100499> configure
updu-100499(config)# users
updu-100499(config-users)# delete old-user
updu-100499(config-users)#
```

The logged-in user cannot delete itself.

10.17.3 Configure a User's SNMPv3 Settings

Each configured user can be enabled for SNMP version 3 access.

To enable SNMPv3 access for the `myuser` :

```
updu-100499> configure
updu-100499(config)# users
updu-100499(config-users)# user myuser
updu-100499(config-users-myuser)# snmpv3 enabled
```

To disable SNMPv3 access for the `myuser` :

```
updu-100499> configure
updu-100499(config)# users
updu-100499(config-users)# user myuser
updu-100499(config-users-myuser)# snmpv3 disabled
```

A user which has SNMPv3 access has permissions according to the user role:

- `admin` users are allowed to read values and switch relays
- `guest` users are allowed to read values only

Users without a role are configured in the SNMP agent, but are unable to request or set anything.

A user's configured password is not relevant for SNMPv3. SNMPv3 is secured with an authentication function (MD5 or SHA1) and an associated password, as well as a privacy function (DES or AES) and password:

Examples:

- Enable SHA1 authentication but no encryption for the currently selected user:

```
updu-100499(config-users-myuser)# snmpv3 auth sha1 password "myAuthPassword"
updu-100499(config-users-myuser)# snmpv3 privacy none
```

- Enable MD5 authentication and AES encryption for the currently selected user:

```
updu-100499(config-users-myuser)# snmpv3 auth sha1 password "myAuthPassword"
updu-100499(config-users-myuser)# snmpv3 privacy aes password "myPrivacyPassword"
```

Notes:

- The authentication and privacy passwords need to be at least 8 characters long.
- It is not possible to encrypt without using authentication.
- Both the SNMPv3 authentication and privacy passwords are stored in clear text and are shown with the `show config` command.

10.18 SSH Configuration

The `ssh` configuration sub-mode allows to control the SSH service.

- Enable the SSH server:

```
updu-100499> configure
updu-100499(config)# ssh
updu-100499(config-ssh)# enabled
updu-100499(config-ssh)#
```

- Disable SSH server:

```
updu-100499> configure
updu-100499(config)# ssh
updu-100499(config-ssh)# disabled
updu-100499(config-ssh)#
```

10.18.1 SSH Session Timeout

By default, SSH sessions are automatically terminated after 15 minutes of inactivity. This timeout can be changed as follows:

- Disable SSH session timeout:

```
updu-100499> configure
updu-100499(config)# ssh
updu-100499(config-ssh)# session-timeout off
updu-100499(config-ssh)#
```

- Terminate inactive SSH sessions after 1 hour:

```
updu-100499> configure
updu-100499(config)# ssh
updu-100499(config-ssh)# session-timeout 60
updu-100499(config-ssh)#
```

Changing the timeout doesn't apply to established sessions, only to new sessions.

10.18.2 Clear SSH Host Keys

The `clear ssh-hostkey` normal mode command clears the host key used by the SSH server. A new key pair is generated the next time the SSH server is restarted (i.e. using the `disabled` / `enabled` SSH configuration commands or using a reboot of the UPDU).

Example:

```
updu-100499> clear ssh-hostkey
SSH host key cleared. A new key pair is generated the next time
the SSH server is started (e.g. after rebooting the UPDU).
```

10.19 Modbus/TCP Configuration

The Modbus/TCP service can be configured using the `modbus/tcp` configuration sub-mode.

- Disable the Modbus/TCP service:

```
updu-100499> configure
updu-100499(config)# modbus/tcp
updu-100499(config-modbus/tcp)# disabled
updu-100499(config-modbus/tcp)#
```

- Enable the Modbus/TCP service:

```
updu-100499> configure
updu-100499(config)# modbus/tcp
updu-100499(config-modbus/tcp)# enabled
updu-100499(config-modbus/tcp)#
```

10.20 Logging

10.20.1 Set Syslog Server

To disable syslog:

```
updu-100499> configure
updu-100499(config)# logging
updu-100499(config-logging)# syslog disabled
updu-100499(config-logging)#
```

To send syslog messages to `192.168.1.1`:

```
updu-100499> configure
updu-100499(config)# logging
updu-100499(config-logging)# syslog server 192.168.1.1
updu-100499(config-logging)#
```

By default, messages are sent with the syslog facility `local0`. This can be changed as follows:

```
updu-100499> configure
updu-100499(config)# logging
updu-100499(config-logging)# syslog server 192.168.1.1 facility local3
updu-100499(config-logging)#
```

By default, messages are sent to port 514 (UDP). This can be changed as follows:

```
updu-100499> configure
updu-100499(config)# logging
updu-100499(config-logging)# syslog server 192.168.1.1 port 1514
updu-100499(config-logging)#
```

10.21 UPDU Object Configuration

The `object` configuration sub-mode can be used to modify the configuration of UPDU objects (e.g. modules, outlets etc.).

10.21.1 Object Description

Using `description`, additional information related to the setup of the PDU can be added to each object.

Example:

```
updu-100499> configure
updu-100499(config)# object Outlet4.1
updu-100499(config-object)# description "Server 42"
updu-100499(config-object)#
```

10.21.2 Object Name

For each object, a case insensitive unique name can be defined which can then be used to address the object.

Example:

- Configure a name for `Outlet2.1`:

```
updu-100499> configure
updu-100499(config)# object Outlet2.1
updu-100499(config-object-Outlet2.1)# name MyServer
```


- Delete a name:

```
updu-100499> configure
updu-100499(config)# object Outlet2.1
updu-100499(config-object-Outlet2.1)# delete name
```

10.21.3 Power Cycle Delay

For switchable outlets, the power cycle delay can be configured. It defaults to 5 seconds.

Example:

- Set the power cycle delay of `Outlet2.1` to 30 seconds:

```
updu-100499> configure
updu-100499(config)# object Outlet2.1
updu-100499(config-object-Outlet2.1)# powercycle-delay 30
```

- Set the power cycle delay to the default value:

```
updu-100499> configure
updu-100499(config)# object Outlet2.1
updu-100499(config-object-Outlet2.1)# powercycle-delay default
```

10.21.4 Rules

With `rules`, it is possible to define conditions which are then monitored. If a condition is not satisfied, a message is logged.

Example:

- Configure that the voltage of Outlet4.1 is expected to be within 10% of 230V (207.0V - 253.0V):

```
updu-100499> configure
updu-100499(config)# object Outlet4.1
updu-100499(config-object-Outlet4.1)# rules
updu-100499(config-object-Outlet4.1-rules)# voltage 207 none none 253
```

10.21.4.1 Current Monitoring

Current monitoring is enabled by defining current thresholds:

```
current <critical-low> <warning-low> <warning-high> <critical-high>
```

Thresholds may be omitted by entering `none`.

Example:

- On WireL1 and WireL2, currents above 8.0A are considered critical. On WireL2, currents between 4.0A and 8.0A generate a warning:

```
updu-100499> configure
updu-100499(config)# object WireL1
updu-100499(config-object-WireL1)# rules
updu-100499(config-object-WireL1-rules)# current none none none 8.0
updu-100499(config)# object WireL2
updu-100499(config-object-WireL2)# rules
updu-100499(config-object-WireL2-rules)# current none none 4.0 8.0
```

10.21.4.2 Voltage Monitoring

Voltage monitoring is enabled by defining voltage thresholds:

```
voltage <critical-low> <warning-low> <warning-high> <critical-high>
```

Thresholds may be omitted by entering `none`.

Example:

- For Outlet4.1, voltages below 207V and above 253V are considered critical, within the [207V, 218.5V] and [241.5V, 253V] ranges they are warning and within the [218.5V, 241.5V] range they are acceptable.

```
updu-100499> configure
updu-100499(config)# object Outlet4.1
updu-100499(config-object-Outlet4.1)# rules
updu-100499(config-object-Outlet4.1-rules)# voltage 207 218.5 241.5 253
```

10.21.4.3 Residual Current Monitoring

Residual current monitoring on RCM modules is enabled by defining current thresholds. Monitoring can be set on RMS or DC current:

```
residual-current rms <warning> <critical>
residual-current dc <warning> <critical>
```

Thresholds may be omitted by entering `none`.

Example:

- Residual RMS currents above 10.0mA are considered critical. Residual RMS currents between 4.5mA and 10.0mA generate a warning. Residual DC currents above 5.0mA are considered critical:

```
updu-100499> configure
updu-100499(config)# object RCM
updu-100499(config-object-WireL1)# rules
updu-100499(config-object-WireL1-rules)# residual-current rms 4.5 10.0
updu-100499(config-object-WireL1-rules)# residual-current dc none 5.0
```

10.21.4.4 Temperature Monitoring

Temperature monitoring is enabled by defining temperature thresholds:

```
temperature <critical-low> <warning-low> <warning-high> <critical-high>
```

Thresholds may be omitted by entering `none`.

Example:

- On Sensor1 and Sensor2, temperatures above 29°C and below 5°C are considered critical. On Sensor2, temperatures between 25°C and 29°C or between 5°C and 10°C generate a warning:

```
updu-100499> configure
updu-100499(config)# object Sensor1
updu-100499(config-object-Sensor1)# rules
updu-100499(config-object-Sensor1-rules)# temperature 5.0 none none 29.0
updu-100499(config)# object Sensor2
updu-100499(config-object-Sensor2)# rules
updu-100499(config-object-Sensor2-rules)# temperature 5.0 10.0 25.0 29.0
```

10.21.4.5 Relative Humidity Monitoring

Relative Humidity monitoring is enabled by defining RH% thresholds:

```
relative-humidity <critical-low> <warning-low> <warning-high> <critical-high>
```

Thresholds may be omitted by entering `none`.

Example:

- On Sensor1 and Sensor2, a relative humidity above 65% and below 35% is considered critical. On Sensor2, a relative humidity between 60% and 65% or between 35% and 40% generates a warning:

```
updu-100499> configure
updu-100499(config)# object Sensor1
updu-100499(config-object-Sensor1)# rules
updu-100499(config-object-Sensor1-rules)# relative-humidity 35.0 none none 65.0
updu-100499(config)# object Sensor2
updu-100499(config-object-Sensor2)# rules
updu-100499(config-object-Sensor2-rules)# relative-humidity 35.0 40.0 60.0 65.0
```

10.21.4.6 Delete Monitoring Rules

The `delete` command allows to delete monitoring rules on an object.

Example:

- Delete all rules on WireL1, delete current monitoring on WireL2:

```
updu-100499> configure
updu-100499(config)# object WireL1
updu-100499(config-object-WireL1)# rules
updu-100499(config-object-WireL1-rules)# delete all
updu-100499(config)# object WireL2
updu-100499(config-object-WireL2)# rules
updu-100499(config-object-WireL2-rules)# delete current
```

10.21.4.7 Disable Monitoring Rules

The `disable` command allows to disable monitoring rules on an object.

Example:

- Disable all rules on WireL1, disable current monitoring on WireL2:

```
updu-100499> configure
updu-100499(config)# object WireL1
updu-100499(config-object-WireL1)# rules
updu-100499(config-object-WireL1-rules)# disable all
updu-100499(config)# object WireL2
updu-100499(config-object-WireL2)# rules
updu-100499(config-object-WireL2-rules)# disable current
```

10.21.4.8 Enable Monitoring Rules

The `enable` command allows to enable monitoring rules on an object.

Example:

- Enable all rules on WireL1, enable current monitoring on WireL2:

```

updu-100499> configure
updu-100499(config)# object WireL1
updu-100499(config-object-WireL1)# rules
updu-100499(config-object-WireL1-rules)# enable all
updu-100499(config)# object WireL2
updu-100499(config-object-WireL2)# rules
updu-100499(config-object-WireL2-rules)# enable current

```

10.22 SSL/TLS Certificates Configuration

In addition to the built-in wildcard SSL/TLS certificate, up to two custom certificates, stored in the certificate stores `store-1` and `store-2` can be configured by the user.

To configure a certificate, two text files containing PEM formatted data are needed:

- A private key (e.g. pdu.domain.key), with a format as follows:

```

-----BEGIN PRIVATE KEY-----
<base64 data>
-----END PRIVATE KEY-----

```

- A certificate (e.g. pdu.domain.crt), with a format as follows:

```

-----BEGIN CERTIFICATE-----
<base64 data>
-----END CERTIFICATE-----

```

The certificate can contain intermediate certificates, in which case multiple `BEGIN/END CERTIFICATE` lines are present.

These two data files are configured in the `certificates` configuration sub-mode:

- Enter the `certificates` configuration sub-mode and choose the one of the certificate stores:

```

updu-100499> configure
updu-100499(config)# certificates
updu-100499(config-certificates)# store-1

```

- Optionally enter a certificate description, for documentation purposes:

```

updu-100499(config-certificates)# description "Datacenter team wildcard cert"

```

- Paste the private key file content:

```

updu-100499(config-certificates-store-1)# key-data
Paste private key in PEM format, end with an empty line or CTRL-c or CTRL-d.
# -----BEGIN PRIVATE KEY-----
# ...
# -----END PRIVATE KEY-----
#

```

- Paste the certificate file content:

```
updu-100499(config-certificates-store-1)# crt-data
Paste certificate in PEM format, end with an empty line or CTRL-c or CTRL-d.
# -----BEGIN CERTIFICATE-----
# ...
# -----END CERTIFICATE-----
# -----BEGIN CERTIFICATE-----
# ...
# -----END CERTIFICATE-----
#
updu-100499(config-certificates-store-1)#
```

The `store-1` certificate can now be used by the webserver, see *Select the SSL/TLS Certificate*.

Having two certificate stores, `store-1` and `store-2`, allows the certificates to be exchanged seamlessly.

10.22.1 Clearing SSL/TLS Certificates

To clear certificate data, use the `clear` command in the certificates store sub-mode:

- Clear everything (description, key, and certificate):

```
updu-100499> configure
updu-100499(config)# certificates
updu-100499(config-certificates)# store-1
updu-100499(config-certificates)-store-1# clear all
```

- Clear description:

```
updu-100499(config-certificates)-store-1# clear description
```

- Clear key:

```
updu-100499(config-certificates)-store-1# clear key
```

- Clear certificate:

```
updu-100499(config-certificates)-store-1# clear certificate
```

11 Licenses

Some UPDU features require purchasing additional licenses.

11.1 Activate Licenses

License can be activated using the `add license` command:

```
updu-100499> add license
Enter license-data, exit with two empty lines or CTRL-c or CTRL-d.
> gwFYQFTP1N90RizCZ8JuHB+AbFSnIhzBCfNryLyVsB1DtFSidMyS0YZfyzRJA85rD+uVK6qLGwP9
> kvCXexpHmaRqUQdUHAeAB1vNFRoAD0cSgYIBZFRlc3Q=
Valid license parsed: S/N 123456789
>
>
Note that newly added licenses will only show up after a reboot.
updu-100499>
```

The `add license` command accepts base64-encoded license data. It ignores comments included with the license data and licenses for other PDUs. When a valid license is found, it is stored in the PDU and a message is printed.

The `add license` command can be quit using two consecutive empty lines or CTRL-c or CTRL-d.

Once activated, licenses cannot be deactivated.

In order to activate the licensed feature, a reboot is required after adding the license.

11.2 Show Licenses

The `show license` command shows all licenses installed in the PDU.

To get the raw base64-encoded license data, use the `show license raw` command. The output is suitable for the `add license` command.

12 UPDU Log Messages

The logging system constitutes an important component of the UPDU firmware. For noteworthy events, messages are logged into an internal log buffer which can be obtained via the CLI or the web interface.

The log buffer is not persistent across reboots of the UPDU. The space in the log buffer is limited. Once the buffer is full, old messages are dropped from the buffer as new messages are logged.

When configured, messages are also sent to a remote server using the syslog protocol (see *Set Syslog Server*) the moment they are logged. Should the network not be ready yet (e.g. after reboot), all messages in the buffer are sent once the network interface is up.

12.1 Log Levels and Log Facilities

Every log message is composed of a timestamp, a log level indicating the severity of the event, a log facility representing the component of the firmware where the event happened, as well as a textual message:

```
<TIMESTAMP> <LOG-LEVEL> <FACILITY>: <MESSAGE>
```

All messages are logged with one of the following four log levels, sorted by their severity:

- **err** : Errors
- **wrn** : Warnings
- **inf** : Informational messages
- **dbg** : Debug messages (hidden by default)

When logging to a remote syslog server, the internal log level is translated into the respective level of the syslog protocol(**LOG_ERR** , **LOG_WARNING** , **LOG_INFO** and **LOG_DEBUG**).

Most messages logged are of informational nature.

Error and warning level messages can point to a temporary problem, a usage or configuration problem, but also a malfunction of the device or an internal firmware error.

Debug messages are disabled by default. For some facilities, these can be activated with the **trace** CLI command (see *Tracing*).

The two most important log facilities from a user perspective are the **monitoring** and the **audit** facility:

- The **monitoring** facility logs messages when the state of a user configured rule changes (e.g. current drawn above configured threshold).
- The **audit** facility logs message when user initiated or certain external events occur (e.g. an outlet is switched or when the PDU is rebooted).

12.2 Monitoring Messages

When a user-configured monitoring rule changes its state, a message is logged by the **monitoring** facility telling what happened to which object and which metric.

All monitoring messages are informational messages and are therefore logged with the **inf** log level, regardless of the monitoring event.

Monitoring messages have the following format:

```
<OBJECT> (<METRIC>): <STATUS> (<INFO>)`
```

Message components are:

- **<OBJECT>** is the name of the object in question, like e.g. **PDU** , **Branch1** or **Outlet2.1** .
- **<METRIC>** is the metric, which is one of the following:
 - Power measurements metrics: **Current** , **Voltage**

- RCM metrics: `Residual Current RMS` , `Residual Current DC`
- Sensor metrics: `Temperature` , `Relative Humidity`
- Over-voltage protection: `OVP fitness`
- System power source (A/C or PoE-powered): `System Power`
- `<STATUS>` is the status of the rule and depends on the actual context:
 - `OK` : The measurement value is back within the expected (good) range.
 - `CRITICAL LOW` : The measurement value is below the *critical-low* threshold.
 - `WARNING LOW` : The measurement value is below the *warning-low* threshold.
 - `WARNING HIGH` : The measurement value is above the *warning-high* threshold.
 - `CRITICAL HIGH` : The measurement value is above the *critical-high* threshold.
 - `FAULT` : A fault has occurred which requires manual intervention to restore good working condition. This is e.g. logged for the `OVP fitness` metric, to indicate that the over-voltage protection has tripped.
 - `FAILOVER` : Some component is in a failover state. This is used when the system is powered by Power over Ethernet instead of A/C (`System Power` metric).
 - `UNKNOWN` : The measurement value is not known. This means that the PDU is unable to obtain a measurement value required to check configured monitoring thresholds. The reason for this can be intermittent communication issue, a missing external sensor or a hardware defect.
- `<INFO>` is optionally logged if additional information about the event is available. It typically contains the measurement value that crossed a threshold, as well as the threshold itself: e.g. `(231.5V>230.0V)` if the measured voltage was 231.5 volts which is above the configured threshold of 230.0 volts.

Examples of monitoring messages:

- The warning high threshold of 230.0 volts on Outlet1.4 was crossed:

```
Outlet1.4 (Voltage): WARNING HIGH (231.5V>230.0V)
```

- The warning low threshold of 4.0 amperes on the entire PDU was crossed:

```
PDU (Current): WARNING LOW (3.5A<4.0A)
```

- The over-voltage protection module connected to the Inlet has failed:

```
Inlet (OVP fitness): CRITICAL FAULT
```

- The temperature cannot be read from the temperature sensor in the AUX2 port (e.g. because there is no sensor plugged in):

```
Sensor2 (Temperature): UNKNOWN
```

- The ICM has lost A/C power and is powered over Power over Ethernet (PoE):

```
PDU (System Power): WARNING FAILOVER (on PoE power)
```

12.3 Audit Messages

For certain important events, mostly user-initiated, a message is logged with the `audit` log facility. Audit messages are informational and logged with the `inf` log level, regardless of what happened.

Audit messages can have different formats and always start with initiator context:

- System-initiated action. Currently limited to `System booted` , which is logged after the PDU has booted and is ready for operation:

```
System <OPERATION>
```

- Operation initiated via the SNMP interface:

SNMP <OPERATION>

- Operation initiated by <USERNAME> via the CLI:

CLI user <USERNAME> <OPERATION>

- Operation initiated by <USERNAME> via the Web interface:

WEB user <USERNAME> <OPERATION>

The following <OPERATION>'s are logged via audit messages:

- Settings are reset to factory defaults: `factory-resets`
- The PDU is rebooted: `reboots PDU`
- A firmware upgrade is initiated: `initiates firmware upgrade`
- An outlet is switched on or off: `switches <OUTLET> [on|off]`
- An outlet is power cycled: `power-cycles <OUTLET>`
- Debug logging is enabled or disabled for a facility: `[enables|disables] tracing <FACILITY>`

Examples of audit messages:

- Outlet1.6 was switched off with an SNMP request:

SNMP switches Outlet1.6 off

- User `john` used the web interface to switch Outlet1.2 on:

WEB user john switches Outlet1.2 on

- User `alice` has entered the `reboot` command in a CLI.

CLI user alice reboots PDU