

UPDU Modbus TCP

Revision: 4.0.0-ee3a859f

Date: 2025-04-15

Contents

1	Overview	3
1.1	Protocol compliancy	3
1.2	Data types and conventions	3
1.3	Reserved and invalid registers	3
2	Supported commands	4
2.1	Read Device Identification (0x2B/0x0E)	4
2.2	Read Input Registers (0x04)	4
3	Device configuration	5
3.1	Unsecure Modbus/TCP	5
3.2	Secure Modbus/TCP	5
4	Print Register Map	8
5	Device identification	9
5.1	Device Identification Objects	9
6	Holding Register Map (Version 1.1)	10
6.1	Global Object Mapping	10
6.2	PDU Information Object	10
6.3	Monitoring Conditions	11
6.4	Sensor Object	11
6.5	RCM Object	12
6.6	Power Object	12

1 Overview

The UPDU features a *Modbus TCP* server which must be enabled before usage. The *Modbus TCP* protocol allows accessing all measurement values of the device using a very simple and efficient protocol.

The current implementation of the *Modbus TCP* protocol allows reading all relevant values of a device and controlling outlets. Writing settings is currently not supported.

1.1 Protocol compliancy

The implementation follows the specifications of the following protocol specifications published by the Modbus Organization:

- MODBUS Application Protocol Specification V1.1b3
- MODBUS Messaging on TCP/IP Implementation Guide V1.0b
- MODBUS/TCP Security Protocol Specification V36

Exceptions and conventions to the above mentioned specifications are described below.

1.2 Data types and conventions

In order to overcome the 16 bit upper size limit for values defined by the *Modbus* specification, a few additional datatypes have been implemented.

- `bitfield` : A single Modbus register representing 16 individual bits.
- `uint16` : A single Modbus register holding a 16-bit unsigned integer.
- `uint32` : 2 Modbus registers to hold a 32-bit unsigned integer.
- `uint64` : 4 Modbus registers to hold a 64-bit unsigned integer.
- `int32` : 2 Modbus registers to hold a 32-bit signed integer.

For any integers spanning over multiple Modbus registers, the data is returned in big-endian format. Thus, the lowest register address contains the most significant bits.

Important: The Modbus server supports reading multiple registers with a single read command. Care must be taken when reading values which span over multiple Modbus registers. Data consistency is only guaranteed for a response to a single read command. It is therefore important to ensure that multi-register values are always obtained with a single read instruction.

1.3 Reserved and invalid registers

In addition to the specified and valid registers, certain addresses contain reserved registers. Reserved registers can be read but will not contain valid information. These are listed as followed:

- `res` : A single register reserved for future or internal use.
- `res[n]` : Multiple (n) registers reserved for future or internal use.

In addition to reserved registers, the global register map defines invalid ranges which are not to be accessed. Any operation on these register addresses will result in returning an error according to the Modbus protocol specification.

2 Supported commands

The following sections describe the currently supported commands. Note that future firmware versions may support additional commands. For details on how to use the commands, refer to the Modbus standards or the documentation of the controller (e.g. PLC).

2.1 Read Device Identification (0x2B/0x0E)

Read device identification (0x0E) is one of the Encapsulated Interface Transport (0x2B) commands. It allows to read identification data from the UPDU.

2.2 Read Input Registers (0x04)

This command is used to read from 1 to 125 continuous input registers from an UPDU.

3 Device configuration

In order to use the Modbus TCP server with a UPDU, the device has to be configured accordingly. The following is a quick start using commands which are documented in the *CLI Reference Manual*.

3.1 Unsecure Modbus/TCP

The simplest configuration variant of the Modbus/TCP server on the UPDU is not recommended for use in real world applications. It has neither authentication nor encryption.

It is configured as follows:

```
updu> configure
updu(config)# modbus/tcp
updu(config-modbus/tcp)# enabled
updu(config-modbus/tcp)# transport plain
updu(config-modbus/tcp)# default-role set guest
updu(config-modbus/tcp)# end
Leaving configuration mode. Use the "write" command to save changes.
updu>
```

This causes the Modbus/TCP server to listen on TCP port 502 on all network interfaces. All connections are accepted and are subject to the permissions defined in the `guest` role. Note that the `guest` role is part of the factory configuration, if it has been removed or modified, adjust the `default-role` setting according to the actual configuration.

3.2 Secure Modbus/TCP

The Modbus/TCP server on the UPDU implements "Modbus/TCP Security" which uses X.509 certificates to provide authentication and authorization.

Secure Modbus/TCP works as follows:

1. Upon connecting to the Modbus/TCP server, the server sends its X.509 certificate allowing the client to authenticate the server.
2. The client sends its X.509 certificate allowing the server to authenticate the client. At this point the connection is mutually authenticated.
3. The client certificate can optionally contain the role of the client, which is then used for authorization.

When step 2 is omitted, the connection is not secure. It is encrypted but has no authentication or authorization of the client. This setup is not recommended for use in real world applications.

When only step 3 is omitted, the connection is secure since it is mutually authenticated. All authenticated connections will use the role defined with the `default-role` setting.

3.2.1 Secure Modbus/TCP Certificates

In order to setup secured Modbus/TCP, the following files are required:

- `ca.key` and `ca.crt` : CA key and certificate used for signing the certificates
- `server.key` and `server.crt` : Private key and certificate signed by the CA
- `client.key` and `client.crt` : Private key and certificate signed by the CA

It is possible to have separate CA for signing client and server certificates. For the sake of brevity we are using the same CA to sign both types of certificates here.

The following code snippets illustrate how these certificates can be generated step by step using OpenSSL:

1. Create a CA:

```
openssl genrsa -out ca.key 4096
openssl req -new -x509 -sha256 -key ca.key -out ca.crt -subj '/CN=ModbusTCP Root CA/'
```

2. Create a server certificate and sign it with the CA:

```
openssl genrsa -out server.key 4096
openssl req -new -sha256 -key server.key -out server.csr -subj "/CN=ModbusTCP Server/" -addext "<SAN>"
openssl x509 -req -in server.csr -CA ca.crt -CAkey ca.key -CAcreateserial \
    -out server.crt -days 1000 -sha256 -copy_extensions copy
```

`<SAN>` is for "subject alternative name" and contains the name of the UPDU to which the Modbus/TCP client will connect. It can be a DNS name such as `subjectAltName=DNS:*.mydc.com` but also an IP address like `subjectAltName=IP:10.11.12.13`.

3. Create a client certificate and sign it with the CA:

```
openssl genrsa -out client.key 4096
openssl req -new -sha256 -key client.key -out client.csr -subj '/CN=ModbusTCP Client/' \
    -addext "1.3.6.1.4.1.50316.802.1=ASN1:UTF8String:my-role"
openssl x509 -req -in client.csr -CA ca.crt -CAkey ca.key -CAcreateserial \
    -out client.crt -days 1000 -sha256 -copy_extensions copy
```

This creates a certificate containing the role `my-role` used for authorization. When the `-addext` parameter is omitted, the role configured with the `default-role` command will be used instead.

3.2.2 Configure the UPDU

1. Configure `store-1` with the server key and certificate:

```
updu> configure
updu(config)# certificates
updu(config-certificates)# store-1
updu(config-certificates-store-1)# key-data
Paste private key in PEM format, end with an empty line or CTRL-c or CTRL-d.
```

Insert the contents of the `server.key` file.

```
updu(config-certificates-store-1)# crt-data
Paste certificate in PEM format, end with an empty line or CTRL-c or CTRL-d.
```

Insert the contents of the `server.crt` file.

```
updu(config-certificates-store-1)#  
updu(config-certificates-store-1)# exit  
updu(config-certificates)#
```

2. Configure `store-2` with the CA certificate:

```
updu(config-certificates)# store-2  
updu(config-certificates-store-2)# crt-data  
Paste certificate in PEM format, end with an empty line or CTRL-c or CTRL-d.
```

Insert the contents of the `ca.crt` file.

```
updu(config-certificates-store-2)#  
updu(config-certificates-store-2)# exit  
updu(config-certificates)# exit  
updu(config)#
```

3. Configure the Modbus/TCP server:

```
updu(config)# modbus/tcp  
updu(config-modbus/tcp)# enabled  
updu(config-modbus/tcp)# transport tls  
updu(config-modbus/tcp)# certificate store-1  
updu(config-modbus/tcp)# auth-certificate store-2  
updu(config-modbus/tcp)# default-role none  
updu(config-modbus/tcp)# end  
Leaving configuration mode. Use the "write" command to save changes.  
updu>
```

At this point a client can connect to the Modbus/TCP server securely using the `client.key`, `client.crt` and `ca.crt` files.

4 Print Register Map

As the actual register map depends on the UPDU model, the CLI allows to print a list with the start address of the object registers:

```
updu> show modbus/tcp
```

Hex	Dec	#	Object	Description
0x0000	0	8		PDU Information
0x0100	256	11		Monitoring Conditions
0x0200	512	16	Sensor1	Sensors
0x0210	528	16	Sensor2	Sensors
0x0220	544	16	Sensor3	Sensors
0x0400	1024	32	PDU	PDU Total Power
0x0500	1280	32	Inlet	Inlet Power
0x0600	1536	32	WireL	Wire Power
0x1000	4096	32	Module0	Module Power
0x2000	8192	32	Outlet0.1	Outlet Power
0x2020	8224	32	Outlet0.2	Outlet Power
0x2040	8256	32	Outlet0.3	Outlet Power
0x2060	8288	32	Outlet0.4	Outlet Power
0x2080	8320	32	Outlet0.5	Outlet Power
0x20a0	8352	32	Outlet0.6	Outlet Power
0x20c0	8384	32	Outlet0.7	Outlet Power
0x20e0	8416	32	Outlet0.8	Outlet Power

Legend:

Hex/Dec: Register address in hexadecimal/decimal notation

#: Number of registers

Object: Corresponding PDU object

Description: Field or register object description

To print a complete register map with all registers, append the `detail` parameter:

```
updu-101718> show modbus/tcp detail
```

Hex	Dec	#	Object	Description
0x0000	0	1		Modbus/TCP register map version
0x0001	1	1		Number of inlet objects
...				

5 Device identification

The UPDU supports Basic, Regular and Specific device identification types with Read Device Identification command. Basic (0x01) and Regular (0x02) gives stream access to a group of identification objects whereas Specific (0x04) gives individual object access.

5.1 Device Identification Objects

Device identification objects supported by the UPDU:

Obj ID	Description	category
0x00	Vendor Name	Basic
0x01	Product Code: Model/Serial Number	Basic
0x02	Firmware Revision	Basic
0x03	Vendor Url	Regular
0x04	Product Name	Regular
0x05	Model Name	Regular

6 Holding Register Map (Version 1.1)

The holding registers are read-only registers which can be obtained by using the Read Input Registers command.

6.1 Global Object Mapping

The following object map specifies the address ranges to read values from a UPDU. Depending on the model, a certain number of object are present.

Start	End	Description
0x0000	0x0007	PDU Information object
0x0008	0x00ff	(Reserved range)
0x0100	0x017f	Monitoring Conditions
0x0180	0x01ff	(Reserved range)
0x0200	0x02ff	Sensor objects (16)
0x0300	0x03ff	RCM objects (16)
0x0400	0x041f	PDU Total Power object
0x0420	0x04ff	(Reserved range)
0x0500	0x05ff	Inlet Power objects (8)
0x0600	0x07ff	Wire Power objects (16)
0x0800	0x0fff	Branch Power objects (64)
0x1000	0x17ff	Module Power objects (64)
0x1800	0x1fff	(Reserved range)
0x2000	0x3fff	Outlet Power objects (256)
0x4000	0xffff	(Invalid range)

6.2 PDU Information Object

The *PDU Information Object* lists the active version of the register map along with the number of available objects per type.

Object total size: 8 Registers

Offset	Type	Description
0x00	uint16	Register Map Version
0x01	uint16	Number of inlets
0x02	uint16	Number of wires
0x03	uint16	Number of branches
0x04	uint16	Number of modules
0x05	uint16	Number of outlets
0x06	uint16	Number of RCMs
0x07	uint16	Number of sensors

6.3 Monitoring Conditions

The *Monitoring Conditions* holds information about active monitoring conditions, arranged by metric.

Added in version 1.1 of the Holding Register Map.

Register map:

Offset	Type	Description
0x00	uint16	Number of active conditions (total)
0x01	uint16	Number of active current conditions
0x02	uint16	Number of active voltage conditions
0x03	uint16	Number of active OVP fitness conditions
0x04	uint16	Number of active RCM current RMS conditions
0x05	uint16	Number of active RCM current DC conditions
0x06	uint16	Number of active Temperature conditions
0x07	uint16	Number of active Relative Humidity conditions
0x08	uint16	Number of active System Power conditions
0x09	uint16	Number of active Differential Pressure conditions
0x0a	uint16	Number of active Branch State conditions
0x0b	res[10]	

6.4 Sensor Object

The values of external sensors connected to the device.

Object total size: 16 Registers

Register map:

Offset	Type	Description
0x00	bitfield	Capabilities
0x01	bitfield	Status
0x02	bitfield	Monitoring
0x03	res	
0x04	uint16	Temperature in 0.1 deg-C
0x05	uint16	Relative humidity 0.1 %RH
0x06	int32	Differential Pressure mPa
0x08	res[10]	

6.4.1 Bitfields

The capabilities, status and monitoring bitfields contain one bit per functionality in this object:

- **Capabilities:** A set bit (1) indicates that a certain functionality supported.
- **Status:** A set bit (1) indicates that the corresponding value is valid. A cleared (0) bit thus indicates an issue with obtaining the measurement.

- **Monitoring:** A set bit (1) indicates that a monitoring condition for the corresponding value is currently active. A clear bit (0) thus indicates that the measurement values are within the good range or no rules have been configured for the value.

The bits are as follows:

- Bit 0: Sensor provides temperature
- Bit 1: Sensor provides relative humidity
- Bit 2: Sensor provides differential pressure

6.5 RCM Object

Offset	Type	Description
0x00	bitfield	Capabilities
0x01	bitfield	Status
0x02	bitfield	Monitoring
0x03	res	
0x04	uint16	Residual RMS current in 0.1 mA
0x05	uint16	Residual DC current in 0.1 mA
0x06	res[10]	

The capabilities, status and monitoring bitfields contain one bit per functionality in this object:

- The bit in the capabilities bitset tells if the functionality is supported (1) or not (0).
- The bit in the status bitset tells if the corresponding field is currently filled with valid data (1) or not (0).
- The bit in the monitoring bitset tells if the corresponding field is currently OK (0) or if a condition is active (1).

The bits are as follows:

- Bit 0: RCM provides residual RMS current
- Bit 1: RCM provides residual DC current

6.6 Power Object

Offset	Type	Operation	Description
0x00	bitfield	Read	Capabilities
0x01	bitfield	Read	Status
0x02	bitfield	Read	Monitoring
0x03	bool	Read/Write	Administrative switching state
0x04	uint32	Read	RMS current in mA
0x06	uint32	Read	RMS voltage in mV
0x08	uint32	Read	Active power in W
0x0a	uint32	Read	Apparent power in var

Offset	Type	Operation	Description
0x0c	uint32	Read	Reactive power in VA
0x0e	uint16	Read	Power factor in per mill
0x0f	uint16	Read	Frequency in 0.001 Hz
0x10	uint64	Read	Positive active energy in Wh
0x14	uint64	Read	Positive reactive energy in varh
0x18	uint64	Read	Negative reactive energy in varh
0x1c	res[4]		

The capabilities, status and monitoring bitfields contain one bit per functionality in this object:

- The bit in the capabilities bitset tells if the functionality is supported (1) or not (0).
- The bits 0-9 in the status bitset tell if the corresponding field is currently filled with valid data (1) or not (0). For objects able to be switched, the bit 15 tells if the operative state is On (1) or Off (0).
- The bit in the monitoring bitset tells if the corresponding field is currently OK (0) or if a condition is active (1).

The bits are as follows:

- Bit 0: Object provides RMS current
- Bit 1: Object provides RMS voltage
- Bit 2: Object provides active power
- Bit 3: Object provides reactive power
- Bit 4: Object provides apparent power
- Bit 5: Object provides power factor
- Bit 6: Object provides frequency
- Bit 7: Object provides positive active energy
- Bit 8: Object provides positive reactive energy
- Bit 9: Object provides negative reactive energy
- Bit 15: Object can be switched